

Personal Protective Equipment Hand Protection Chemical Resistant



Gloves, Insulated Neograb™, heavy-duty Neoprene® coating, PPE Category III

S4



Rough finished, fully coated, heavy-duty Neoprene® coating. Unique triple layer construction of foam insulation between a layer of 100% cotton jersey and 100% cotton interlock. Excellent resistance to oils and greases. Good abrasion, cut and tear resistance. Very effective to both cold and intermittent heat.

Catalogue No	Alt. No	Size	Pack type	Pack qty
SAR-328-090T	6781R-10	10	Pair	1



Gloves, gauntlets, PVC with nitrile, chemical resistant, red, Hustler™, PPE Category III

S4



Fully coated PVC with nitrile reinforced coating offering excellent chemical and abrasion resistance. Sanitized® two piece cotton interlock liner. Sanded on rough finish provides excellent non-slip wet grip.

Catalogue No	Type	Length, mm	Size	Pack type	Pack qty
SAR-152-090E	Fully coated	305	10	Pair	1
SAR-153-090V	Fully coated	355	10	Pair	1
SAR-154-090P	Fully coated elbow-length	430	10	Pair	1



Gloves, PVC, chemical resistant, Sempersoft, PPE Category III

S4



High quality, reusable, green PVC gloves on a smooth and soft cotton lining. Anatomically handed in pairs these gloves are 1.1mm thick at the palm and have a length of 310mm with a straight cuff and have an AQL of 1.5. On the outside is a structured rough surface in a grip pattern for excellent handling especially in wet conditions. Free of latex proteins and accelerators this PVC glove offers excellent general chemical resistance. Length 300mm.

Chemical resistance data for this glove is available at www.sempermed.com. Select the industrial gloves section from European Branch and then click on 'English', then 'Products', and then from the list headed 'Chemical Protective Gloves' select 'Sempersoft' and then click on 'Show List' for chemicals. Alternatively you can access the 'Products' section of the Sempermed® site for this information via the Fisher Scientific website.

Catalogue No	Size	Pack type	Pack qty
SAR-734-030W	Small	Pair	12
SAR-734-050Q	Medium	Pair	12
SAR-734-070K	Large	Pair	12
SAR-734-090E	Extra large	Pair	12



Gloves, nitrile, chemical resistant, Premium Sol-Vex™, PPE Category III

S4



A premium nitrile glove providing new standards of safety for high risk chemical handling. Each glove is individually air-pressure tested. Manufactured from a newly developed nitrile film which offers greater strength and superior chemical resistance, suitable for particularly hazardous chemical areas, e.g. chemical manufacture, transfer of aggressive chemicals and handling chemical mixtures. Other areas for use include oil refining, laboratory testing and the handling of pesticides, insecticides and plant protection chemicals. Sanitised®/Actifresh® with dot pattern reverse lozenge grip that actually strengthens the glove. Flock lined with semi-gauntlet length for better forearm protection. Lozenge style. Colour red. Length 380mm, thickness 0.425mm.

Catalogue No	Size	Pack type	Pack qty
SAR-610-030W	7	Pair	12
SAR-610-050Q	8	Pair	12
SAR-610-070K	9	Pair	12
SAR-610-090E	10	Pair	12
SAR-610-110B	11	Pair	12

